

MODA SPARKLING WATER SYSTEM
INSTALLATION INSTRUCTIONS + CHECKLIST
FREECALL: 1800-006632



A. VENTILATED LOCATION (#1)

- i. Position unit to optimise ventilation:
All condenser vents exposed with 20cm clearance
- ii. System <1metre from font/tap location
- iii. **** DO NOT INSTALL INSIDE A CABINET ****
CALL MODA BEFORE PROCEEDING

B. WATER IN + ICE BATH (#2 + #3)

- i. Set up water as below
- ii. **** VERY IMPORTANT ****
Flush filter into ice bath and fill (to b/w min-max level)



C. FONT & TAPS (#4 + #5)

- i. Mount font to bench
- ii. Tighten taps with C-Spanner to font
- iii. Add super seal connectors to tubes at base of font;
connect (with minimum run) hose to machine

D. TURN ON (#7)

- i. Turn on water, check for leaks
- ii. Bleed still tap, then sparkling water tap
- iii. Turn on power; set thermostat at 6.25

E. ADD GAS (#6)

- i. Affix chain to wall to loop over gas regulator
- ii. Fit reg to tank, run hose to system (elbow at machine)
- iii. Set pressure at 3.8 bar; 380kpa; do drop test to check for leaks

F. FINAL CHECKS

- i. Check machine is venting warm air across condenser
- ii. Check Sparkling water is filling a minimum of 2 bottles
- iii. Leave Basics leaflet + multi spanner for gas with client