

CHANGING GAS

MODA
Sparkling

USE ONLY FOOD GRADE CO2



1. Turn off gas tank
2. Draw glass of sparkling water to release pressure in line
(**Don't try to remove while pressure is still in line**)
3. Unscrew regulator from tank; turn L
4. Screw regulator to new tank; turn R
5. Turn on gas at bottle and both gauges flick up



Simple check for leaks

1. Turn tank off at the bottle for 2 minutes
2. Check both gauges stay in position
3. If not, remove regulator and repeat
If persistent, O-ring may be lost/flat & needs replacing

Pressure gauge

Typical setting 380kpa (+/-20)

Pressure adjust

Turn R to turn UP

Lock nut behind is set to constrict past a set pressure (e.g. 400kpa)

ON/OFF valve

ON = turn run parallel to line

Spare O-rings

Rubber seal affixed to shaft

Contents gauge

Green = Full

Red = empty

Estimate 200L sparkling water per kg of co2; small tank = 6kg

Vent

Vents over 400kpa
Safety feature

